






Ko Shan Theatre - Level 1 Dressing Room  
 高山劇場 - 一樓化妝間



Dressing Room 1 and 1a : 4 persons  
 (化妝間房號：人數)



Ko Shan Theatre - Level 2 Dressing Room  
高山劇院 - 二樓化妝間





Ko Shan Theatre - Level 3 Dressing Room  
高山劇院 - 三樓化妝間

EXIT

STAGE LEFT,  
BACKSTAGE  
ENTRANCE  
台左, 後台入口

STAGE RIGHT  
台右

EXIT

Dressing Room 5  
(12 persons)  
化妝間五 (12人)

Dressing Room 6  
(12 persons)  
化妝間六 (12人)

